DIAMOND BLADE APPLICATION CHART

		BEST PERFORMAN		CE/LIFE/SPEED GO	
	RANGE	600 Pro	600 Pro	200 Trade	100 Value
TILE - HARD DENSE	CODE TYPE	SCR10	VTP	MXCR30	VXCR30
MATERIALS		CONTINUOUS RIM	ULTRA THIN X TURBO CONTINUOUS RIM	CONTINUOUS RIM	CONTINUOUS RIM
PORCELAIN (PEI HARDNESS CLASS 1-5)	HARDER	***	***	**	**
PORCELAIN (PEI HARDNESS CLASS 1-3)		***	***	**	***
ENGINEERED ARTIFICIAL STONE		***	***	***	***
GRANITE		***	***	***	***
QUARTZITE		***	***	***	***
CERAMIC TILES		***	***	***	***
CLAY PIPE - ROOF TILES		***	***	*	*
CLAY PAVERS	VESS	***	***	*	*
QUARRY TILES	MATERIAL HARDNESS	***	***	***	***
TERRACOTTA	MATE	***	***	***	***
INDIAN STONE (KOTA)		***	**	×	×
TRAVERTINE		***	***	***	***
PORPHYRY		***	***	**	**
BASALT		***	***	**	**
HARD SLATE		***	***	***	***
SOFT SLATE		***	***	**	**
MARBLE	SOFTER	***	***	***	***
					8-8-8-8-8



IF A DIAMOND TOOLS STARTS TO SLOW DOWN OR STOPS CUTTING WHEN CUTTING PRODUCTS NOT IDEALLY SUITED, DRESS THE BLADE BY USING IT IN A NORMAL MANNER ON ABRASIVE PRODUCTS SUCH AS ABRASIVE COARSE SANDSTONE OR ASPHALT TO DRESS THE DIAMONDS & OPEN UP THE BOND. THIS MAY NEED TO BE REPEATED WHEN NEEDED.

WHEN USING A DIAMOND TOOL & EXCESSIVE SPARKS ARE BEING CREATED OR SIGNS OF WHEEL "WOBBLE" THEN STOP USING IMMEDIATELY & USE A BLADE WITH A SOFTER BOND IDEALLY SUITED TO THE APPLICATION.